

Site Name: Westlake Landfill		Site Conta	ct: David Kinroth	1			Telephone: 913-220-5887 (cell)	
cation: Bridgeton, Missouri	Clien	t Contact:				elephone: 816-516-4954 (cell) 13-551-7058 (work)		
EPA ID No.	F	Prepared E	By: Rick Claytor			Date F	Date Prepared: 4/15/2014	
Project No. 9025.14.0058.000		Dates of A	ctivities: April 28	, 2014 an	d forward	Emerg	gency Response □Yes ⊠No	
Objectives:		Site	Type: Check as	many as	applicable.			
START will provide support to EPA Region 7 implementing an air monitoring plan to sample for landfill constituents prior to the isolation barrier installation around the Westlake landfill. The plan is to docume		\boxtimes	Active	\boxtimes	Landfill		Inner-City	
			Inactive		Railroad		Rural	
background conditions off the site prior to construction activities a construction activities to determine if any releases are occurring			Secured	\boxtimes	Residential		Remote	
construction activities to determine it any releases are occurring ab- health based benchmarks. The monitoring will be conducted until the barrier installation is completed.			Unsecured		Industrial		Other (<i>specify</i>)	
Project Scope of Work and Site Background The potential hazardous releases into the air around an ongoing subsurface smoldering event at the Westlake Landfill in Bridgeton, Missouri will be monitored before during and after the barrier installation. Up to 5 monitoring locations surrounding the site in addition to on-site monitoring. We plan to sample for typical solid waste landfill gases such as sulfur dioxide (SO2), hydrogen sulfide (H2S), carbon monoxide (CO) and volatile organic compounds (VOCs). Radiation monitoring for radon, alpha, beta and gamma emissions will also be conducted.								
Health and Safety Approver Comments or Additional Instructions: This HASP SHALL be revised at each site visit as appropriate to ensure that the hazards associated with the assigned tasks have been identified and proper safety controls implemented. All information provided in this HASP (and any applicable attachments) have been reviewed and made site-specific by proper hazard identification and control techniques. This method of risk assessment is done in the field at the time of work being conducted. Changes to this HASP (or AHA) shall be documented and approved by a safety manager.								
Health and Safety Plan Approver Signature:						Date:		

Note: A minimum of two persons with appropriate training and medical surveillance must be on site for any fieldwork subject to Level 2 HASP requirements.

Note: A detailed site sketch or figure may be included on Page 10 of 12.

11 February 2010 Page 1 of 12



Initial Isolation Distance:	sitial Isolation and Protective Action Distances (for emergency response operations only): Use the 2012 Emergency Response Guidebook (ERG) as appropriate sitial Isolation Distance: This zone should extend in all directions; 660 feet for unknown hazards and 0.5 mile for tanker truck or rail car incidents. OTE: Keep a maximum distance away for unknown sites until the identity of the materials is determined.						
ubsequent Isolation and Protection Action Zones Based on Air Monitoring Results: OTE: Distance at sites with unknown hazards should be increased, if necessary, based on air monitoring results.							
Wind Speed and Directio	n (Approach from upwind)	Tem	perature (°F)	Relative Humidity (Probability of recipitation (%)	Weather Forecast (such as partly cloudy, snow, etc.)
Speed (mph):	From Direction:	1011	•				P during all field activities.
On-Site Supplies:	⊠ First Aid Kit	⊠ Fire	Extinguisher	☐ Air Horn	1	☐ Oral Therm	nometer
Known or Anticipated Si	Known or Anticipated Site Hazards or Concerns: (Hazards covered by existing Safe Work Practices are listed on the next page)						
☐ Work on active roadwa	ay		Overhead utili	ties		☐ Energized elec	ctrical systems
☐ Onsite laboratory			Buried Utilities	S		☐ Portable hand	tool use
☐ Explosion or fire hazar	rd		Surface or un	derground storage tank	ks [□ Portable electr	rical tool use
☐ Oxygen deficiency		\boxtimes	General slips,	trips, falls		☐ Machine guard	ding
☐ Unknown or poorly cha	aracterized chemical hazards		Uneven, mude	dy, rugged terrain		⊠ Portable fire ex	xtinguisher use
			Lift (man lift, c	herry picker) use		☐ Driving comme	ercial vehicles
			Industrial trucl	k (forklift) use		☐ Driving person	al vehicles
☐ Chemical warfare mat	eriel		Wood or meta	l ladder use		☐ Scientific divin	g operations
☐ Compressed Gas Cyli	inders		Dangerous go	ods shipped by air		☐ Injury and Illne	ess Prevention Program (California only)
☐ Asbestos		×		(over 6' high) (work o anent fall barrier)	on [☐ Ergonomics (C	California only)
☐ Respirable particulate	s		Heavy equipm	nent use or operation		□ Work in strip o	r shaft mines
☐ Respirable silica			Construction v	vork		☐ Client-specific	safety requirements (attach to HASP)
☐ Blasting and explosive	es		Excavation or	trenching		☐ ATV use	
☐ Non-ionizing radiation	(lasers, radiofrequencies, UV)		Benching, sho	oring, bracing		☐ Methamphetar	mine lab
⊠ Ionizing radiation (alpl	ha, beta, gamma, etc.)		Scaffold use			☐ Working over o	or near water
			High noise			□ Mold	
			Grinding oper	ations		☐ Other (insert)	
Explosion or Fire Potent	ial: □ High		☐ Medium		⊠ Low		☐ Unknown

11 February 2010 Page 2 of 12



Che	mical Products Tetra Tech FM	Inc. Will Use or Store On Site: (Attach a Materia	l Safety	Data Sheet [MSDS] for each iter	n)	
	Alconox or Liquinox	☐ Calibration gas (Methane)		Hydrogen gas	,	Isopropyl alcohol
	Hydrochloric acid (HCI)	<u> </u>		Household bleach (NaOCI)		HazCat Kit
	Nitric acid (HNO ₃)	☐ Calibration gas (Pentane)		Sulfuric acid (H ₂ SO ₄)		Mark I Kits (number?)
	Sodium hydroxide (NaOH)	- , , , , , , , , , , , , , , , , , , ,		Hexane		Other (specify)
	· · · · ·	Il be readily available on ALL projects where co				
***************************************	-	afe Work Practices (SWP). Attach to HASP:		ks Performed At Job Site that a		
	DCN 4-03 Demolition and Decon	, ,		TE: Many AHA's can be found or		
	DCN 4-05 Demolition and Decom			http://home.ttemi.com/C18/Ad	ctivity%	620Hazard%20Analysis%20Doc
	DCN 4-08 Asbestos Protection P			um/default.aspx	•	j
	DCN 4-09 Haulage and Earth Mo	oving	Atta	nch Activity Hazard Analysis (AHA) for e	ach non-covered task
	DCN 4-10 Lead Protection Progr		\boxtimes	outdoor ambient air		
\boxtimes	SWP DCN 5-01 General Safe W			(non-covered task)		
\boxtimes	SWP DCN 5-02 General Safe W			(non-covered task)		
	SWP DCN 5-03 Safe Work Pract			(non-covered task)		
	SWP DCN 5-04 Safe Drilling Pra SWP DCN 5-05 Safe Direct Push			(non-covered task)		
	SWP DCN 5-06 Working Over or		Ι.,			
	SWP DCN 5-07 Use of Heavy Ed	nuipment	ret	ra Tech Employee Training and	weak	cai Requirements:
		ards (Firearms, Remote Sites, Mines, aircraft, etc.)		Basic Training and Medical		
	SWP DCN 5-09 Safe Electrical V			⊠Initial 40 Hour Training		
\boxtimes	SWP DCN 5-10 Fall Protection P			⊠8-Hour Supervisor Training (one	e_time`	
\boxtimes	SWP DCN 5-11 Portable Ladder			⊠Current 8-Hour Refresher Train	ina	•
	SWP DCN 5-12 Drum and Conta			⊠Current Medical Clearance (incl		respirator use)
	SWP DCN 5-13 Flammable Haza SWP DCN 5-14 Spill and Discha			⊠Current First Aid Training		
	SWP DCN 5-14 Spin and Discha	ge Control Practices		⊠Current CPR Training		
\boxtimes	SWP DCN 5-16 Cold Stress			□Current Respirator Fit-Test		
	SWP DCN 5-17 Biohazards					
	SWP DCN 5-18 Underground St			Other Specific Training and Med	dical S	Surveillance Requirements
	SWP DCN 5-19 Safe Lifting Prod			☐Confined Space Training		
	SWP DCN 5-22 Hydrographic Da			□Level A Training		
		Confined Space Entry Practices uired Confined Space Entry Practices		□Radiation Training	f. t. T.	No No
\boxtimes	SWP DCN 5-24 Non-Fermit-Req			□OSHA 10-hour Construction Sa □OSHA 30-hour Construction Sa		
	SWP DCN 5-27 Respirator Clear			☐ Asbestos Awareness Training	iety i i	aming
	SWP DCN 5-28 Safe Use Praction			☐ Asbestos Awareness Training ☐ Asbestos B-Reader X-Ray		
	SWP DCN 5-29 Respirator Quali	tative Fit Testing Procedures		☐Blood Lead Level and ZPP Pre	. durin	g and Post-Project
	SWP DCN 5-30 Laboratory Soil	Festing Safe Work Practices		\square Urinary Arsenic Level Pre and $ ilde{F}$	ost-P	roject
				□ Other		
				□ Other		
			1			

11 February 2010 Page 3 of 12





Materials Present or Suspected at Site	Highest Observed Concentration (specify units and sample medium)	Exposure Limit (specify ppm or mg/m³)	IDLH Level (specify ppm or mg/m³)	Primary Hazards of the Material (explosive, flammable, corrosive, toxic, volatile, radioactive, biohazard, oxidizer, or other)	Symptoms and Effects of Acute Exposure	Photoionization Potential (eV)
sulfur dioxide (SO2)	U	PEL = 15 mg/m3 REL = .10 mg/m3 TLV =	100 mg/m3	toxic	Irritation eyes, nose throat,\; rhin; chocking, cough; reflex bronchionstriction	12.3
hydrogen sulfide (H2S),	U	PEL = 20 ppm REL = 15 mg/m3 TLV =	100 ppm	Toxic, flammable	Irrit eyes,resp sys; apnea, coma, convuls; corn visic; dizz, head,f tg, irrit, insom, derm	NA
carbon monoxide (CO)	U	PEL = 55 mg/m3 REL = 40 mg/m3 TLV = NA	1200 ppm	Flammable, toxic	head, tachypnea, nau, weak, blurred vision, dizziness, slurred speech, confusion, convulsions	14.01
radon, alpha, beta and gamma	No readings above naturally occurring background levels	PEL =. REL = TLV =		radioactive		NA
Non-specified volatile organic compounds	U	PEL = Various REL = TLV =	Various	Volatile, flammable	Various, but include nausea, headache, and vomiting.	Various
		PEL = REL = TLV =				

Specify Information Sources: For example: NIOSH Pocket Guide to Hazardous Chemicals, September 2005 and American Conference of Governmental Industrial Hygienists (ACGIH). "Threshold Limit Values and Biological Exposure Indices for 2009."

Note: In the Exposure Limit column, include Ceiling (C) and Short-Term Exposure Limits (STEL) if they are available. Also, use the following short forms and abbreviations to complete the table above.

A = AirCARC = Carcinogenic eV = Electron volt

U = Unknown

IDLH = Immediately dangerous to life or health mg/m³ = Milligram per cubic meter

NA = Not available

NE = None established

PEL = Permissible exposure limit

ppm = Part per million

REL = Recommended exposure limit

S = Soil

TLV = Threshold limit value

11 February 2010 Page 4 of 12



Note: If no contingency level of protection is selected, all employ require upgrading PPE. Level A field work requires a Level 3 HAS				inant levels
Field Activities Covered Under this HASP:				
Tack Deceription	-	Level of	Date of Activities	
Task Description 1 Ambient air monitoring		Primary □A □B □C ⋈ D	Contingency □A □B ⊠C □ D	
				April 25 forward
2		□A □B □C □ D	□A □B □C □ D	
3		\square A \square B \square C \square D	□A □B □C □ D	
4		□A □B □C □ D	□A □B □C □ D	
5		□A □B □C □ D		
Site Personne	l and Responsibilities (inclu	de subcontractors):		
Employee Name and Office Code / Location	Task(s)		Responsibilities	
David Kinroth, Project Manager Rob Monnig	1	coordinator (SSC) aw maintains communica projects lasting longe responsible for condu Field Team Leader: I (SSC) aware of pertin communications with Site Safety Coordinat protective equipment	nages the overall project, makes are of pertinent project development on with client as necessary. A rethan one consecutive week onciting one field audit using Form Directs field activities, makes site nent project developments and plethe Project Manager and the client (SSC): Ensures that approprise (PPE) is available, enforces project beontractors; suspends investige	nents and plans, and additionally, For site, the PM is AF-1. safety coordinator ans, and maintains and maintains are personal per use of PPE by on-
Greg Blattner, SCC	1	are or may be expose enforces the HASP; is communicates site has observed from anticip plan to the health and Alternate Site Safety Field Personnel: Comteam leader, and SSG established in the Tet Tetra Tech-hired subs	ed to an immediate health hazard dentifies and controls site hazard azards to all personnel; and reportated conditions described in the disafety representative. Coordinator (if any) Inpletes tasks as directed by the pc, and follows the HASP and all stra Tech, Inc., Health and Safety contractor personnel on site (a si	; implements and s when possible; ts any deviations health and safety roject manager, field SWPs and guidelines Manual.
		MUST be identified by scope of work in acco Tech on-site safety m	y name): Completes tasks as out ordance with the contract. Partici eetings and follows all procedure SP, as well as the company hea	lined in the project pates in all Tetra es and guidelines

Note

11 February 2010 Page 5 of 12

^{1.} See next page for details on levels of protection



NOTE: Contingency level of protection section should be completed only if the upgraded level of protection is immediately available at the job site. If no contingency level of protection is denoted, all employees covered under this HASP must evacuate the immediate site area if air contaminant levels would require an upgrade of PPE.

Protective Equipment: (Indicate type or material as necessary for each task.)

Tas k	Primary Level of Protection (A,B,C,D)	PPE Component Description (Primary)	Contingency Level of Protection (A, B, C, D)	PPE Component Description (Contingency)
1	D	Respirator type: NA Cartridge type (if applicable): NA CPC material: NA Glove material(s): Jersey & nitrile Boot material: Steel toe and shank Other: Safety glasses, hard hat, safety vest	С	Respirator type: Full-face APR Cartridge type (if applicable): Organic vapors, P100 CPC material: Tyvek coveralls Glove material(s): Nitrile Boot material: Steel toe and shank Other: hard hat, safety vest
2		Respirator type: Cartridge type (if applicable): CPC material: Glove material(s): Boot material: Other:		Respirator type: Cartridge type (if applicable): CPC material: Glove material(s): Boot material: Other:
3		Respirator type: NA Cartridge type (if applicable): CPC material: NA Glove material(s): Boot material: Other:		Respirator type: Cartridge type (if applicable): CPC material: Glove material(s): Boot material: Other:
4		Respirator type: Cartridge type (if applicable): CPC material: Glove material(s): Boot material: Other:		Respirator type: Cartridge type (if applicable): CPC material: Glove material(s): Boot material: Other:
5		Respirator type: Cartridge type (if applicable): CPC material: Glove material(s): Boot material: Other:		Respirator type: Cartridge type (if applicable): CPC material: Glove material(s): Boot material: Other:

Resnirator Notes:

Respirator cartridges may only be used for a maximum time of 8 hours or one work shift, whichever is less, and must be discarded at that time. For job sites with organic vapors, respirator cartridges may be used as described in this note as long as the concentration is less than 200 parts per million (ppm), the boiling point is greater than 70 °Celsius, and the relative humidity is less than 85 percent. If any of these levels are exceeded, a site-specific respirator cartridge change-out schedule must be developed and included in the HASP using Tetra Tech Form RP-2 (Respiratory Hazard Assessment Form)

Notes:

All levels of protection must include eye, head, and foot protection.

CPC = Chemical protective clothing

Thermoluminescent Dosimeter (TLD) Badges must be worn during all field activities on sites with radiation hazards. TLDs must be worn under CPC.

11 February 2010 Page 6 of 12



Monitoring Equipment: All monitoring	equipmen	it on site must be calibrated before ar	d after each use and results recorded	l in the site logbook	
Instrument (Check all required)	Task	Instrument Reading	Action Guideline	Comments	
☐ Combustible gas indicator model:	□ 1 □ 2	0 to 10% LEL	Monitor; evacuate if confined space		
	□ 3 □ 4 □ 5	10 to 25% LEL	Potential explosion hazard; notify SSC		
		>25% LEL	Explosion hazard; interrupt task; evacuate site; notify SSC		
☐ Oxygen meter model:	□ 1 □ 2	>23.5% Oxygen	Potential fire hazard; evacuate site		
	□ 3 □ 4 □ 5	23.5 to 19.5% Oxygen	Oxygen level normal		
		<19.5% Oxygen	Oxygen deficiency; interrupt task; evacuate site; notify SSC		
⊠ Radiation survey meter model:	⊠ 1 □ 2	Normal background	Proceed	Annual exposure not to exceed 1,250 mrem per quarter	
TLDs, Alpha Track Detectors, Particulate monitors (Radecos), E- Perms (Radon), and Saphymo Genitron	□ 3 □ 4 □ 5	Two to three times background	Notify SSC	Background reading must be taken in an area known to be free of radiation sources.	
Gamma Tracers,		>Three times background	Radiological hazard; interrupt task; evacuate site; notify RSO		
□ Photoionization detector model: □ 11.7 eV	□ 1□ 2□ 3□ 4□ 5	Any response above background to 5 ppm above background	Level B is recommended Level C ^a may be acceptable	These action levels are for unknown gases or vapors. After the contaminants are identified, action levels should be based on the specific contaminants involved.	
		> 5 to 500 ppm above background	Level B	specific contaminants involved.	
		> 500 ppm above background	Level A		
☐ Flame ionization detector model:	□ 1 □ 2	Any response above background to 5 ppm above background	Level B is recommended Level C ^a may be acceptable	These action levels are for unknown gases or vapors. After the contaminants are identified, action levels should be based on the	
	□ 3 □ 4 □ 5	>5 to 500 ppm above background	Level B	specific contaminants involved.	
		>500 above background	Level A		
□ Detector tube models:	□ 1 □ 2 □ 3 □ 4 □ 5	Specify: < 1/2 the PEL > 1/2 the PEL	Specify:	The action level for upgrading the level of protection is one-half of the contaminant's PEL. If the PEL is reached, evacuate the site and notify a safety specialist	
⊠ Other (specify): MultiRae / AreaRae / PbRae	⋈ 1□ 2□ 3□ 4□ 5	Specify: CO – 9ppm SO2 – Day:0.10 ppm Night: 0.40 ppm H2S – Day: 0.30 ppm Night:1.00 ppm VOC – Day: 5.0 ppm Night: 10.0 ppm	Specify: Alarm levels: additional monitoring will be conducted to determine if additional actions are required.		

Notes:

eV= electron volt LEL=Lower explosive limit mrem=Millirem PEL=Permissible exposure limit ppm=Part per million

11 February 2010 Page 7 of 12

a. Level B is required when chemical hazards are present, but are uncharacterized. Level C may be acceptable for certain tasks in some situations. If you are uncertain, consult your RSO.



Project-Specific Industrial Hygiene Requirements	Emergency Contacts:	Telephone No.
OSHA-Regulated Chemicals*:	WorkCare and Incident Intervention 888.44	9.7787, or 800.455.6155
Check any present on the job site in any medium (air, water, soil)	Tetra Tech EMI 24-hour Anonymous Hazard Reporting Line	866.383.8070
□ No chemicals below are located on the job site	U.S. Coast Guard National Response Center	800.424.8802
☐ Friable Asbestos	InfoTrac	800.535.5053
☐ Silica, crystalline	Poison Control	
□ alpha-Napthylamine □ Methyl chloromethyl ether		800.222.1222
□ 3,3'-Dichlorobenzidine (and its salts)	Fire department	911 (417) 623-0403
□ bis-Chloromethyl ether	Police department	911 (417) 623-3131
□ beta-Napthylamine	Personnel Call-Down List:	
□ Benzidine	Job Title or Position: Name	Cell Phone:
□ 4-Aminodiphenyl	Regional Safety Officer Denny Cox	(816) 668-7464
□ Ethyleneimine	Project Manager: David Kinroth	(314) 517-6798
□ beta-Propiolactone	Field Team Leader:	
☐ 2-Acetylaminoflourene	Site Safety Coordinator (SSC):	
☐ 4-Dimethylaminoazobenzene	Subcontractor SSC:	
□ N-nitrosomethylamine□ Vinyl chloride		
☐ Inorganic arsenic	Medical and Site Emergencies:	
□ Lead	Signal a site or medical emergency with three blasts of a loud horr	(car horn, fog horn, or
☐ Chromium (VI)	similar device). Site personnel should evacuate to the area of safe	
□ Cadmium	the site map.	
□ Benzene	Hospital Name: SSM DePaul Health Center	
☐ Coke oven emissions	·	
☐ 1,2-Dibromo-3-chloropropane	Address: 12303 DePaul Drive, Bridgeton, MO 63044	
☐ Acrylonitrile		
☐ Ethylene oxide	General Phone:	(314) 344-6000
☐ Formaldehyde☐ Methylenedianiline	Emergency Phone:	911
□ 1,3-Butadiene	Ambulance Phone:	911
☐ Methylene chloride	Hospital called to verify emergency services are offered? YES	NO □
* NOTE: Many states, including California and New Jersey, have chemical-specific worker protection requirements and standards for many chemicals and	Step-by-step Route to Hospital: (see Page 11 of 12 for route map)	
known or suspected carcinogens.	1. 1. Head southwest on Taussig Rd toward St Charles Rock Rd	0.2 mi
	2. Turn left onto St Charles Rock Rd	1.3 mi
	3. Turn right onto De Paul Dr	289 ft
	4. Turn right to stay on De Paul Dr	0.1 mi
	5. Turn left to stay on De Paul Dr	0.2 mi
	6. Turn right to stay on De Paul Dr Destination will be on the right	423 ft

Note: This page must be posted on site.





11 February 2010 Page 9 of 12



Decontamination	on Procedures	Emergency Response Planning
The site safety coordinator overseas implementation of project decontamination procedures and is responsible for ensuring they are effective.		During the pre-work briefing and daily tailgate safety meetings, all on-site employees will be trained in the provisions of emergency response planning, site communication systems, and site evacuation routes.
Personnel Decontamination	Decontamination Equipment	In the event of an emergency that necessitates evacuation of a work task
Level D Decon - □ Wet ⊠ Dry		 area or the site, the following procedures will take place. The Tetra Tech SSC will contact all nearby personnel using the on-site
Level C Decon - □ Wet ⊠ Dry	⊠ Buckets	communications to advise the personnel of the emergency.
Level B Decon – Briefly outline the level B	⊠ Scrub brushes	The personnel will proceed along site roads to a safe distance upwind from the hazard source.
decontamination methods to be used on a separate page attached to this HASP.	□ Pressurized sprayer	The personnel will remain in that area until the SSC or an authorized
Level A Decon – A Level 3 HASP is	☑ Detergent [Alconox]	individual provides further instructions.
required. Notify your regional health and	☐ Solvent [Type]	In the event of a severe spill or a leak, site personnel will follow the
safety representative and health and safety director.	\square Household bleach solution	procedures listed below. Evacuate the affected area and relocate personnel to an upwind location.
Equipment Decontamination	Concentration/Dilution:	Inform the Tetra Tech SSC, a Tetra Tech office, and a site representative
All tools, equipment, and machinery from	□ Deionized water	 immediately. Locate the source of the spill or leak, and stop the flow if it is safe to do so.
the Exclusion Zone (hot) or	☐ Disposable sanitizer wipes	Begin containment and recovery of spilled or leaked materials.
Contamination Reduction Zone (warm) are decontaminated in the CRZ before	□ Facemask sanitizer powder	Notify appropriate local, state, and federal agencies.
they are removed to the Support Zone	☐ Wire brush	In the event of severe weather, site personnel will follow the procedures
(cold). Equipment decontamination procedures are designed to minimize the	⊠ Spray bottle	 listed below. Site work shall not be conducted during severe weather, including high
potential for hazardous skin or inhalation	☐ Tubs / pools	winds and lightning.
exposure, cross-contamination, and chemical incompatibilities.	☐ Banner/barrier tape	In the event of severe weather, stop work, lower any equipment (drill rigs) and evacuate the affected area.
Respirator Decontamination	☐ Plastic sheeting	Severe weather may cause heat or cold stress. Refer to SWPs 5-15 and 5- 16 for information on both.
Respirators are decontaminated in	☐ Tarps and poles	To for information on both.
compliance with SWP 5-27 and should be included with this HASP.	⊠ Trash bags	All work-related incidents must be reported. According to TtEMI's
Waste Handling for Decontamination	⊠ Trash cans	 reporting procedures, for non-emergency incidents you should: Notify WorkCare and Incident Intervention at 888.449.7787, or
Procedures for decontamination waste	⊠ Duct tape	800.455.6155
disposal meet all applicable local, state,	⊠ Paper towels	 Notify your Project Manager or Regional Safety Officer (RSO) via phone immediately.
and federal regulations.	☐ Folding chairs	Complete a "Tetra Tech Incident Report" (Form IR) within 24 hours and send the years BCO. If an injury or illness has accoursed, the Forms IR A and the
	☐ Other	it to your RSO. If an injury or illness has occurred, the Form IR-A and the WorkCare HIPAA form must be completed at the same time the Form IR is completed.

11 February 2010 Page 10 of 12




Site Map (May be drawn after crews arrive onsite or inserted using aerial photographs, site figures, etc.):	

1 February 2010 Page 11 of 12



Note: A dry-run should be conducted to establish a physical locationids location from the hospital emergency room should also be obtained to ensure that the hospital will accept chemically contaminated patients.

Taussig Rd to 12303 De Paul Dr, Bridgeton, MO 63044 - Googl... https://maps.google.com/maps?saddr=earth.city.missouri&dadd...



Bridgeton, MO 63044

11 February 2010 Page 12 of 12



APPROVAL AND SIGN-OFF FORM

Project No.: X9025.14.0058.000

I have read, understood, and agree with the information set forth in this Health and Safety Plan and will follow the direction of the Site Safety Coordinator (SSC) as well as procedures and guidelines established in the Tetra Tech, Inc., Health and Safety Manual. I understand the training and medical requirements for conducting field work and have met these requirements.

Tetra Tech has prepared this plan solely for the purpose of the health and safety protection of Tetra Tech employees. Subcontractors, visitors, and others at the site, while required to read and follow the provisions outlined in this plan at a minimum, should refer to their safety program for specific information related to their health and safety protection.

Name	Company / Agency / Organization	Signature	Date
I have read, understood, and agree with the inforestablished in the Tetra Tech, Inc., Health and S	 rmation set forth in this Health and Safety Plan and afety Manual.	 d comply with and will enforce this HASP, as well as	procedures and guidelines
Name	Project-Specific Position	Signature	Date
David Kinroth	Project Manager		
	Field Team Leader		
	Site Safety Coordinator		
	Subcontractor SSC		

Tetra Tech has prepared this plan solely for the purpose of the health and safety protection of Tetra Tech employees. Subcontractors, visitors, and others at the site, while required to read, acknowledge and follow the provisions outlined in this plan at a minimum, should refer to their safety program for specific information related to health and safety.

Note: Use Additional sheets as necessary to ensure that all personnel sign and affirm this document.

11 February 2010 Page 13 of 12

Emergency Contacts

- **WorkCare** For issues requiring an Occupational Health Physician; assistance is available 24 hours per day, 7 days per week.
- **InfoTrac** For issues related to incidents involving the transportation of hazardous chemicals; this hotline provides accident assistance 24 hours per day, 7 days per week
- **U.S. Coast Guard National Response Center** For issues related to spill containment, cleanup, and damage assessment; this hotline will direct spill information to the appropriate state or region

Poison Control Center - For known or suspected poisoning.

Limitations:

The Level-Two HASP is not appropriate in some cases:

- Projects involving unexploded ordnance (UXO), radiation sources as the primary hazard, or known chemical/biological weapons site must employ the Level 3 HASP
- Projects of duration longer than 90 days may need a Level 3 HASP (consult your RSO)

Decontamination:

- Decontamination Solutions for Chemical and Biological Warfare Agents^a: PPE and equipment can be decontaminated using 0.5 percent bleach (1 gallon laundry bleach to 9 gallons water) for biological agents (15 minutes of contact time for anthrax spores; 3 minutes for others) followed by water rinse for chemical and biological agents. In the absence of bleach, dry powders such as soap detergents, earth, and flour can be used. The powders should be applied and then wiped off using wet tissue paper. Finally, water and water/soap solutions can be used to physically remove or dilute chemical and biological agents. Do not use bleach solution on bare skin; use soap and water instead. Protect decontamination workers from exposure to bleach.
- **Decontamination for Radiological and Other Chemicals:** Primary decontamination should use Alconox and water unless otherwise specified in chemical specific information resources. The effectiveness of radiation decontamination should be checked using a radiation survey instrument. Decontamination procedures should be repeated until the radiation meter reads less than 100 counts per minute over a 100-square-centimeter area when the probe is held 1 centimeter from the surface and moving slower than 2.5 centimeters per second.
- **Decontamination Corridor:** The decontamination setup can be adjusted to meet the needs of the situation. The decontamination procedures can be altered to meet the needs of the specific situation when compoundand site-specific information is available.
- **Decontamination Waste:** All disposable equipment, clothing, and decontamination solutions will be double-bagged or containerized in an acceptable manner and disposed of with investigation-derived waste.
- **Decontamination Personnel:** Decontamination personnel should dress in the same level of PPE or one level below the entry team PPE level.
- All investigation-derived waste should be left on site with the permission of the property owner and the EPA on-scene coordinator. In some instances, another contractor will dispose of decontamination waste and investigation-derived waste. DO NOT place waste in regular trash. DO NOT dispose of waste until proper procedures are established.

Notes:

Source: Jane's Information Group. 2002. Jane's Chem-Bio Handbook. Page 39.



TETRA TECH, INC. DAILY TAILGATE SAFETY MEETING FORM

Date:	Time:	Project No.:	
Client:		Site Location:	
Site Activities Plan	ned for Today:		
Weather Conditions	s:		
		/ Topics Discussed	
Protective clothi	ing and equipment:	Topics Discussed	
	g aa eqa.pe		
Chemical and ph	nysical hazards:		
Emergency proc	edures:		
Equipment haza	rds:		
Other:			
		Attendees	
	Printed Name	Signature	
Meeting Conducte	ed by:		
Name		Signature	



TETRA TECH EM INC. HEALTH AND SAFETY PLAN AMENDMENT

Site Name:			
Amendment Date:			
Purpose or Reason for <i>I</i>	Amendment:		
Required Additional Saf	e Work Practices or Act	tivity Hazard Analyses:	
Required Changes in PF	PE:		
Action Level Changes:			
	AMENDME	NT APPROVAL	
RSO or Designee			
	Name	Signature	Date
Site Safety Coordinator	Name	Signature	Date
ate presented during d	laily site safety meeting	:	



TETRA TECH, INC. FIELD AUDIT CHECKLIST

Project Name: _	Project No.:
Field Location: _	Completed by:
Project Manager:	Site Safety Coordinator:

		ı			
General Items			In Compliance?		
Health	and Safety Plan Requirements	Yes	No	NA	
1	Approved health and safety plan (HASP) on site or available				
2	Names of on-site personnel recorded in field logbook or daily log				
3	HASP compliance agreement form signed by all on-site personnel				
4	Material Safety Data Sheets on site or available				
5	Designated site safety coordinator physically present on jobsite				
6	Daily tailgate safety meetings conducted and documented on Form HST-2				
7	Documentation available proving compliance with HASP requirements for medical examinations, fit testing, and training (including subcontractors)				
8	HASP onsite matches scope of work being conducted				
9	Emergency evacuation plan in place and hospital located				
10	Exclusion, decontamination, and support zones delineated and enforced				
11	HASP attachments present onsite (VPP sheet, audit checklist, AHA, etc.)				
12	Illness and injury prevention program reports completed (California only)				
Emerg	ency Planning			•	
13	Emergency telephone numbers posted				
14	Emergency route to hospital posted				
15	Local emergency providers notified of site activities				
16	Adequate safety equipment inventory available				
17	First aid provider and supplies available				
18	Eyewash solution available when corrosive chemicals are present				
Air Mo	nitoring				
19	Monitoring equipment specified in HASP available and in working order				
20	Monitoring equipment calibrated and calibration records available				
21	Personnel know how to operate monitoring equipment and equipment manuals available on site				
22	Environmental and personnel monitoring performed as specified in HASP				

	Safety Items		In Co	ompliar	ice?
Personal Protection			Yes	No	NA
23	Splash suit, if required				
24	Chemical protective clothing, if required				
25	Safety glasses or goggles (always required)				
26	Gloves, if required				
27	Overboots, if required				
28	Hard hat (always required)				
29	High visibility vest, if required				
30	Hearing protection, if required				
31	Full-face respirator, if required				
Instru	umentation	,			
32	Combustible gas meter and calibration notes				
33	Oxygen meter and calibration notes				
34	Organic vapor analyzer and calibration notes				
Supp	olies				
35	Decontamination equipment and supplies				
35	Fire extinguishers				
37	Spill cleanup supplies				
Corre	ective Action Taken During Audit:				
Note:	NA = Not applicable				
Auditor's Signature Site Safety Coordinator's Signature					
Date					

T.	Tetra	Tech,	Inc.
----	-------	-------	------

ACTIVITY HAZARD ANALYSIS (AHA)

Tetra Tech EM Inc.

Ambient Outdoor Air Monitoring

Task Description

This Activity Hazard Analysis (AHA) applies to the task listed above. It has been developed and approved by the Director of Health and Safety for Tetra Tech EMI. The AHA contains potential hazards posed by each major step in this task, lists procedures to control hazards, and presents required equipment (including safety equipment), inspections, and training. The hazard controls listed below are specific to this task.

START will provide support to EPA Region 7 implementing an air monitoring plan to sample for landfill constituents prior to the isolation barrier installation around the Westlake landfill. The plan is to document background conditions off the site prior to construction activities and during construction activities to determine if any releases are occurring above health based benchmarks. The monitoring will be conducted until the barrier installation is completed.

Hazards		Actions	
Task Steps	Potential Hazards	Critical Safety Procedures and Controls	
Setup/maintain/access monitoring stations (ground level stations)	Vehicular traffic	Field personnel will wear orange safety vests.	
	Slips, trips, falls	Field personnel will wear steel-toed boots with good tread.	
Setup/maintain/access monitoring stations (roof mounted stations)	Falls	One roof-top location is anticipated. The roof area was observed during an initial site visit and a permanent 4-foot tall barrier enclosed the portion of the roof that will be accessed. Field personnel will stay within the barrier so that there is not risk of falling.	
Equipment to be Used No special safety instruments/equipument is required (PPE only)	Inspection Requirements NA	Training Requirements NA	

Assessed By			
•	Name	Signature	Date
Approved By			

Name Signature Date